# Digital Impression Guide

### *CEREC Connect and Cadent iTero*

## Add us as a CEREC Connect Favorite Contractor

1. Access the link www.cerec-connect.com, and login with your office credentials.
2. On the left hand side you will see the tab "Partner" and underneath access "My Favorite Contractor",
3. Select "Search Contractor" and select "Search Direct".
4. Clear out the "Zip Code" and "City" fields.
5. Type "PFD Digital Lab" in the "Name of Contractor" field and select "Start Search".
6. Click the plus (+) sign and then select "Confirm".

## Add us as an iTero Partner Lab

1. Call iTero customer support at (800) 577-8767.
2. Select option 1 when prompted.
3. Request that PFD Digital Lab is added to your scanner.
4. After PFD Digital Lab has been added, restart your scanner.
5. After connecting to us as a lab, select PFD Digital Lab on your scanner to send files.

**PFD DIGITAL**
LABORATORY AND DESIGN CENTER

www.pfddigital.com          (855) 500-6731